

PowerWalker VFI 3/3 Series
VFI 30000TP/40000TP 3/3 BE/BI
380/400/415V 50/60Hz
(3-phase input/output)
User Guide

©2013 BlueWalker GmbH

All Rights Reserved

The contents of this manual are the copyright of the publisher and may not be reproduced (even extracts) unless permission granted. Every care has been taken to ensure the accuracy of the information contained in this manual, but no liability can be accepted for any errors or omission. The right to make design modifications is reserved.

Contents

1. Safety instructions.....	01
1.1 Safety caution.....	01
1.2 Audience caution.....	01
1.3 CE marking.....	02
1.4 User precaution.....	02
1.5 Environment.....	03
1.6 Inquiries.....	03
2. Introduction.....	04
2.1 System description.....	04
2.2 Basic system configuration.....	05
2.3 Panel figure.....	05
2.4 Exterior figure.....	06
3. Technical data.....	08
3.1 Standards.....	08
3.2 Environment.....	08
3.3 Dimensional drawings.....	08
3.4 Characteristics.....	09
3.5 AC input.....	09
3.6 DC circuit.....	09
3.7 AC output.....	10
3.8 Battery and charger.....	10
4. Mechanical installation.....	11
4.1 Delivery check.....	11
4.2 Unpacking and visual inspection.....	11
4.3 Planning before installation.....	13
4.4 Cabinet installation.....	14
4.5 Maintenance Bypass Switch (MBS).....	14

5. Electrical installation.....	21
5.1 Electrical Preparations.....	21
5.2 Installation and wire connection diagram.....	21
5.3 Suggested cable and protective devices.....	24
5.4 Internal Battery Installation.....	26
5.5 Connecting the external battery.....	34
5.6 Connections between battery cabinet and UPS.....	35
5.7 Handling the batteries.....	36
6. Software and connectivity.....	37
7. User operations.....	40
7.1 Single machine operation.....	40
7.2 Parallel machine operation.....	48
8. Maintenance.....	51
8.1 Battery Maintenance.....	51
8.2 Regular service/intervals.....	53
8.3 Cooling fan.....	53
9. Parallel systems.....	54
10. Recycling the used UPS or battery.....	56
11. Display reference Table.....	57

1 Safety instructions

This user manual contains important safety instructions and operating instructions. Please read the user manual carefully before operating or working on the UPS and save it for reference in the future.

1.1 Safety caution

The UPS operates with external AC mains, battery cabinet(s) or bypass power. It contains components that carry hazardous voltages and high currents, The properly installed enclosure is earthed and IP20 rated against electrical shock and foreign objects. The user is not permitted to open it. Failure to observe this could result in electric shock risk.

Only qualified personnel is allowed to install and service the UPS.



Warning!

Operations inside the UPS must be performed by a service engineer from the manufacturer or from an agent authorised by the manufacturer.

Use the optional Maintenance Bypass Switch (MBS) for service inside the UPS when installed to the system. Remember to open battery cabinet(s) breaker. Always ensure by measuring with a multimeter that no dangerous voltages are present. For detailed MBS operation instructions please see 4.5.

1.2 Audience caution

The intended audiences of this manual are people who plan the installation, install, commission, and use or service the UPS. The manual provides guidelines to check delivery, installing and commissioning of the UPS. The reader is expected to know the fundamentals of electricity, wiring, electrical components and electrical schematic symbols. This manual is written for a global reader.



Caution!

Read the manual before operating or working on the UPS.

EN

1.3 CE marking

The product has the CE marking in compliance with the following European directives:

LVD Directive (Safety)	2006/95/EEC
EMC Directive	2004/108/EEC



Note!

This product for commercial and industrial application in the second environment Installation restrictions or additional Measures may be needed to prevent disturbances.

1.4 User precaution

The only user operations permitted are:

Start up and shut down the UPS, excluding the commissioning start-up. Use of the LCD control panel and Emergency Power Off (EPO) switch. Use of optional connectivity modules and their software. The user must follow the precautions and only perform the described operations. Any deviations from the instructions could be dangerous to the user or cause accidental load loss.



Warning!

The user is not permitted to open any screws excluding connectivity plates and the Emergency Power Off (EPO) switch. Failure to recognise the electrical hazards could prove fatal.

1.5 Environment

The UPS must be installed according to the recommendations in this manual. Under no circumstances the UPS should be installed in an airtight room, in the presence of flammable gases, or in an environment exceeding the specification. Excessive amount of dust in the operating environment of UPS may cause damage or lead to malfunction. The UPS should be always protected from the outside weather and sunshine. The recommended operating temperature is from +15 to +20 Celsius degrees. The recommended operating humidity: 20% to 90%.

1.6 Inquiries

Address any inquiries about the UPS and battery cabinet(s) to the local office or agent authorized by the manufacturer. Please quote the type code and the serial number of the equipment.

2 Introduction

The product described in this manual is an Uninterruptible Power Supply (UPS). It is a true online, continuous duty, double conversion, solid state, three-phase system, providing conditioned and uninterruptible AC power to protect the end-user's load.

EN


2.1 System description

PowerWalker VFI 3/3 Series products are high-efficiency and high-performance, double conversion, pure-online and three phase input and three phase output UPS, with unit capacity ranging between 20KVA-40KVA. Categorized by capacity, the products can be further divided into 20KVA, 30KVA and 40KVA. This series not only provides perfect solution for power source protection and successfully solves problems such as blackout, boost, brownouts, sags, decaying, oscillation, high voltage impulse, voltage fluctuations, surges, harmonic distortion, disturbances, frequency fluctuation etc, but also enhances adaptability to complicated working environments so that the application fields is well extended to computer equipments, communication equipments and other controlling equipments with good adaptability to complicated industrial environments as well. Therefore, this series products can be applied in a diversified multi-industries field such as telecommunications, financing, transportation, government, manufacturing and energy sectors.


PowerWalker VFI 3/3 Series products are also capable of ECO mode. ECO mode means UPS load is powered by bypass AC supply while in case of abnormal AC supply the load will be supplied by accumulator battery after conversion through inverter. As the energy conversion efficiency reaches as high as 98% and transfer time less than 10ms under ECO mode when there is normal AC supply, the energy saving effect of UPS is remarkable.

Remark: ECO mode is applicable only to single unit.

2.2 Basic system configuration




2.3 Panel figure




- ① AC: This light and inverter light will turn "green" when UPS is powered by Rectifier Input;
 - ② Inverter: This light will turn "green" when UPS load is through the inverter;
 - ③ Battery: This light will turn "yellow" when UPS is powered by batteries;
 - ④ Bypass: This light will turn "green" when UPS load is powered by Bypass Input;
 - ⑤ Fault: If the UPS worked under fault condition, this light would turn on and stay "red" with continuous warning tone being given off in case of UPS abnormal function; or flash "red" with intermittent warning tone being given off.
 - ⑥ LCD: Display UPS commands.
 - ⑦ : Confirm/Enter; press this button to select a menu or confirm an operation.
 - ⑧ : PageDown; press this button to switch to next screen display under the same menu.
 - ⑨ : PageUp; press this button to return to next screen display under the same menu.
 - ⑩ Esc: Escape; press this button to return to previous menu or cancel a certain operation.
- Remark: Refer to Chapter 12 for detailed information of LED in accordance with UPS condition.**

2.4 Exterior view

Exterior figure of PowerWalker VFI 3000TP 3/3 BE/BI, 4000TP 3/3 BE/BI UPS





3 Technical data

3.1 Standards

EN

UPS	VFI 30000TP 3/3 BE/BI	VFI 40000TP 3/3 BE/BI
Safety	IEC62040-1:2008, EN62040-1:2003 and EN60950-1:2005	
EMC	IEC62040-2:2006 and EN62040-2:2005	
Product	IEC62040-3:1999 and EN62040-3:2001	

3.2 Environment

UPS	VFI 30000TP 3/3 BE/BI	VFI 40000TP 3/3 BE/BI
Working Temperature	0°C ~ +40°C	
Storage Temperature	-30°C ~ +65°C (without batteries)	
	0°C ~ +40°C (with batteries)	
Relative Humidity	5% ~ 90%, no condensation allowed	
Altitude derating coefficient	See user operations section for more detail information	
Vibration	IEC68-2-6; max. 0.3mm (2 to 9Hz), max. 1m/s ² (9 to 200Hz) sinusoidal	

3.3 Dimensional drawings

UPS	VFI 30000TP 3/3 BE/BI		VFI 40000TP 3/3 BE/BI	
W×D×H (mm)	470*700*1752.5	Without package	470*700*1752.5	Without package
	974*743*2008	With package	974*743*2008	With package
Net Weight (Kg)	195	Without batteries	195	Without batteries
	515	With batteries	515	With batteries
Gross Weight (Kg)	255	Without batteries	255	Without batteries
	575	With batteries	575	With batteries

3.4 Characteristics

	VFI 30000TP 3/3 BE/BI	VFI 40000TP 3/3 BE/BI
Noise (ISO 7779)	<57dB at 75% load	
Efficiency-nominal load	Up to 92%	

3.5 AC input

	VFI 30000TP 3/3 BE/BI	VFI 40000TP 3/3 BE/BI
Rectifier input	3 phases + N	
Bypass input	3 phases + N	
Voltage (L-N)	121V-274 Volts without using battery	
Frequency	40-70 Hz	
Power factor	0.99	
Input distortion	< 5% THD(I)	
Rated input voltage	380V/400 V/415V	
Rated input current	43A/41A/40A	57A/54A/52A

3.6 DC circuit

Battery number	2 × 16	
Battery nominal voltage	Positive battery	+192V DC
	Negative battery	-192V DC
Cut off voltage	154 ± 2V DC (when load > 2kw)	
	176 ± 2V DC (when load ≤ 2kw)	
Battery charging current (A)	± 4.5A	

3.7 AC output

		VFI 30000TP 3/3 BE/BI	VFI 40000TP 3/3 BE/BI
Active power		24KW	32KW
Number of phases		3-phases + N	
Frequency		50/60HZ	
Voltage (L-N)		220/230/240 VAC	
Overload capability (Mains available)	110%<Load<=125%	10 minutes minimum, then transfer to bypass and alarm	
	125%<Load<=150%	1 minutes minimum, then transfer to bypass and alarm	
	Load>150%	0.5 seconds minimum, then transfer to bypass and alarm	
Overload capability (battery available)	110%<Load<=125%	10 minutes minimum, then transfer to bypass and alarm	
	125%<Load<=150%	1 minutes minimum, then transfer to bypass and alarm	
	Load>150%	0.5 seconds minimum, then transfer to bypass and alarm	

3.8 Battery and Charger

		VFI 30000TP 3/3 BE/BI	VFI 40000TP 3/3 BE/BI
Internal battery package		Panasonic LC-RW 1245W / CSB HR 1234WF2	
Dimensions		94*151*64.5/pc(Panasonic)	94*151*65/pc(CSB)
Strings		2 x 16	
Stored energy time		up to 860s At Rated liner Load,25°C	up to 540s At Rated liner Load,25°C
Restored energy time		<8Hours Up to 90% charge	
Charger Input Protection		8 A fuse	
Rated Charge Voltage		±216V Default for Integrated bettery	
Initial Charging Current		4.5A	
Battery Leakage		< 3.5mA	
Battery protection		30A Fuse*3 For PCBA level	30A Fuse*2*3 For PCBA level
		125A Breaker	
Max discharging current		87A Ubat=308VDC,Full RCD load	116A Ubat=308VDC,Full RCD load

4 Mechanical installation

The UPS and accessories are delivered on a specifically designed pallet that is easy to move with a forklift or a pallet jack. Keep the UPS always in upright position and do not drop the equipment. Do not stack the pallets.

4.1 Delivery check

The UPS is delivered with the following items:

1. Winpower disc
2. RS-232 serial cable
3. User Guide
4. Key
5. Battery kit(wires & trays)(Only for model without batteries)

4.2 Unpacking and visual inspection

Check that there are no signs of shipping damages. The equipment should be transported in the upright position.





Note!

A claim for shipping damage must be filed immediately and the carrier must be informed within 7 days of receipt of the equipment. The packing materials should be stored for further investigation.

Unpack the equipment by removing the packing and shipping materials. Make a visual inspection. Remove the equipment from the pallet and make sure that the floor surface is solid and suitable for the wheeling and heavy weight.


Remove cover plate → Remove side plate → Remove stuffing and fix



Check the information on the type designation label of the equipment to verify that the unit is of the correct type. The type designation label includes ratings, a CE marking, a type code, a part number and a serial number. The serial number is important when making inquiries. It allows individual recognition of the equipment.

4.3 Planning before installation

The equipment must be installed in upright position. The equipment requires space to front and back to enable cooling airflow. Service and maintenance require more than 500mm clearance on right hand side. All cooling air enters at front and exits at unit rear. The required minimum clearance from unit rear to an obstruction is 400mm. Because the service and user access is in the front there should be reserved enough space (min 800mm).



Preparation for installation.

1. Avoid extremes of ambient temperature; excessive dust, moisture or vibration; flammable gases; and corrosive or explosive atmospheres.
2. Altitude for normal UPS function should not exceed 1000m.
3. The battery cabinet should work within a temperature range from 15°C to 25°C .
4. The maximum ambient temperature for normal UPS performance should not exceed 40°C .

4.4 Cabinet installation



Note!

Please use stabilizing devices to fix the UPS prior to the installation.

EN


The required distance for UPS units should allow for service access. The same applies to the battery cabinet(s) that should be installed next to the UPS cabinet(s).



Caution!

UPS cabinet(s) can fall over if the installation brake pads are not used. Both rear and front pads must be used to secure the UPS cabinet to the floor.

Use a 19mm wrench in clockwise direction to screw the brake pad down to the ground, keeping the machine from moving.



4.5 Maintenance Bypass Switch(MBS)




Warning!

All operations inside the unit must be performed only by a service engineer from the manufacturer or from an agent, authorised by the manufacturer.

The operation of the MBS is allowed for a service engineer from the manufacturer or from an agent, authorised by the manufacturer. The full UPS wiring diagram with a MBS switch is presented in the installation part of the manual.

The maintenance positions of the MBS switches



EN

Transfer UPS from normal mode to maintenance bypass mode:

1. The normal start position should be following:

Maintenance switch	Rectifier Input	Bypass Input	N	Battery breaker
OFF	ON	ON	ON	ON


2. Use LCD to turn the UPS from normal mode to bypass mode:

Switch-off action (press ESC to exit above picture)

1) Switch-off picture



2) If it is in single machine mode, the following will appear



Remember to verify the transfer before proceeding the next step.

3. Remove the locking plate of maintenance switch.

4. Turn OFF the Rectifier Input switch and battery breaker.

Maintenance switch	Rectifier Input	Bypass Input	N	Battery breaker
OFF	OFF	ON	ON	OFF


5. Turn the Maintenance switch to "MAINTENANCE" side.

Maintenance switch	Rectifier Input	Bypass Input	N	Battery breaker
ON	OFF	ON	ON	OFF

6. Turn OFF the Bypass Input switch and N switch.

Maintenance switch	Rectifier Input	Bypass Input	N	Battery breaker
ON	OFF	OFF	OFF	OFF

7. UPS is now in the maintenance bypass mode, see below (Note: the Serv disconnect i.e. battery breaker must be turned off):



EN

Transfer UPS from maintenance bypass mode to normal mode:

1. The normal start position should be following:

Maintenance switch	Rectifier Input	Bypass Input	N	Battery breaker
ON	OFF	OFF	OFF	OFF

2. Turn ON the Bypass Input switch and N switch

Maintenance switch	Rectifier Input	Bypass Input	N	Battery breaker
ON	OFF	ON	ON	OFF

When the LED of bypass turns green, the UPS enters into bypass mode.

3. Turn the Maintenance switch to “UPS” side.

Maintenance switch	Rectifier Input	Bypass Input	N	Battery breaker
OFF	OFF	ON	ON	OFF

Then the UPS turn to bypass mode.

4. Turn ON the Rectifier Input switch and battery breaker.

Maintenance switch	Rectifier Input	Bypass Input	N	Battery breaker
OFF	ON	ON	ON	ON


5. Use LCD to turn the UPS from bypass mode to normal mode:

Switch-off action (press ESC to exit above picture)


1) Switch-on picture



2) Press ENTER



6. UPS is now in the normal mode, see below:



EN

7. Remount the locking plate of maintenance switch to the position to prevent the use of it.

5 Electrical installation

5.1 Electrical Preparations



Note!

It must be ensured that no line input source can accidentally be connected to the UPS during installation.



Warning!

Installation may only be carried out by qualified technicians and in conformity with the applicable safety standards.



Warning!

The UPS unit is not applicable to the IT power distribution system.

5.2 Installation and wire connection diagram

The UPS unit has the following power connections:

Three-phase (L1, L2, L3), Neutral (N) and Protective Earth (PE) connection for the rectifier input.

Three-phase (L1, L2, L3), Neutral (N) and Protective Earth (PE) connection for the bypass input (N is INTERNALLY common for rectifier and bypass inputs).

Three-phase (L1, L2, L3), Neutral (N) and Protective Earth (PE) connection for the load output.

Positive pole (+), Negative pole (-), Common midpoint/Neutral pole and Protective Earthing (PE) connection for the external batteries.

56 red wires (B2) with an approximate length of 70mm, 4 red wires (B3) with an approximate length of 770mm and 8 red wires (B4) with an approximate length of 65mm for BAT+;


4 red wires (B9, B10 and B11) for BAT+ connection;

4 blue wires (B5) with an approximate length of 65 mm, 4 blue wires with an approximate length of 770mm (B6) for BATN;

8 blue wires (B14, B15, B16, and B18) for BATN connection;
 56 black wires (B1) with an approximate length of 70mm, 8 black wires (B7) with an approximate length of 770mm and 4 black wires (B8) with an approximate length of 65mm for BAT-;
 4 black wires (B12, B13, and B17) for BAT- connection.

EN

1.If UPS rectifier input and bypass input are supplied from two mains:
 Connect the mains 1 supply cables to the UPS rectifier input terminals L1, L2, L3, N and PE.
 Connect the mains 2 supply cables to the UPS bypass input terminals L1, L2, L3, N and PE.




2.If UPS rectifier input and bypass input are supplied from one mains only:

Connect the mains supply cables to the UPS rectifier input terminals L1, L2, L3, N and PE .

The following three jumpers must be fixed between the rectifier and bypass input terminals:

L1-L1, L2- L 2, L3- L3.



Terminal block diagram

Warning!

High touch current earth connection essential before connecting supply.


In order to gain access to the external electrical connections it is necessary to remove the front terminal protective panel of the UPS. Before the cables are connected they shall be passed through the cable glands to hold them in position and tightened.

Connect the Protective Earthing (PE) cable first.

Connect other cables as shown in the connection terminal representations on the preceding and following pages.

EN

Ensure that the UPS is isolated before removing front terminal protective panel.



5.3 Suggested cable and protective devices

Caution!
 All cables should always use copper cable type.

The conductor cross sections apply for maximum currents:

- (1) For PVC-insulated copper cables (at 70°C)
- (2) When routed in conduits for electrical installations
- (3) When air temperature surrounding the conduits does not exceed 30°C
- (4) For cable lengths up to 30 m

Notice!
 Should there be any variation in the conditions it will be necessary to verify whether the cable dimensions satisfy the requirements of IEC-287 and DIN VDE 0298. In cases where the cables are so long that they cause a drop in voltage of >3%, a larger dimension shall be selected.

Routing of communication cables or data lines should be kept separate from the UPS input, output, and external battery cables.

Use cable cross section and protective device specification

Model	VFI 30000TP 3/3 BE/BI	VFI 40000TP 3/3 BE/BI
Rectifier Input L1, L2, L3, N, Bypass Input L1, L2, L3, N, min. conductor cross section[mm ²] max. possible cross section[mm ²]	10 35	16 35
Rectifier Input L1, L2, L3, N breaker (A)	80A 230VAC	100A 230VAC
Bypass Input L1, L2, L3, breaker (A)	80A 230VAC	100A 230VAC
Rectifier Input fuse (A)	80A 250VAC	100A 250VAC
Bypass Input fuse	80A 250VAC	100A 250VAC
Internal battery switch	125A 690VAC	
Output L1, L2, L3, N, min. conductor cross section[mm ²] max. possible cross section[mm ²]	10 35	16 35
External Battery Cabinet Positive pole(+),Neutral pole,Negative pole (-), min. conductor cross section[mm ²] max. possible cross section[mm ²]	16 35	25 35
External Battery Cabinet Fuse (A) in Positive pole(+),Neutral pole, Negative pole (-),	120A 250VAC	150A 250VAC
External Battery Cabinet breaker (A) in Positive pole(+),Neutral pole,Negative pole (-),	120A 250VAC	150A 250VAC
Backfeed protection device	60A 250V AC Clearance distances:>=1.4mm Break time<=15s	
Protective Earthing conductor [mm ²]	Max 35	
Torque for fixing above terminals	2.8-3 Nm	

**Notice!**

The following label must be displayed on all switching devices installed in the same electrical system as the UPS, even when these are located at a distance from the area in which it is located (according to European standard EN 62040-1).

**Warning!**

ENSURE THAT THE UNINTERRUPTIBLE POWER SYSTEM IS ISOLATED BEFORE WORKING ON THIS CIRCUIT.

EN


5.4 Internal Battery Installation

REMARK:**THE FOLLOWING WARNINGS SHOULD BE OBSERVED DURING THE OPERATION:**

- The batteries may contain potential electric shock danger because of high voltage.
- Wear safety goggles.
- Make sure to verify battery polarity before connecting.
- Make sure to keep wires away from the adjacent legs and sharp edges of shelves handles.


Please complete the procedure below to install batteries:

1. Make sure that the breaker is in off position (Located in front of the unit).
2. Remove the eighteen screws on the battery cover and take off the battery cover (see Fig.1).




3. Assemble the battery packs. There are eight batteries in each battery pack, four packs in each shelf and total is four shelves.


Step1: Put batteries into the trays (see Fig. 2).



Step2: connect the wires between the batteries (see Fig. 3).




Please refer to the following figure(Fig.4) for wire connections of the four battery packs.




EN


Step3: Install the top tray downward, and fold both the top and bottom tray flanges (see Fig 5).




Step4: Tape two sides (see Fig.6).Make sure the cable is placed between the tray edges during tape mounting.



Step5: Paste the labels to the battery packs (see Fig. 7).



Make sure to paste the correct label to each battery pack and the battery packs are placed conformably with the labels, i.e. the battery terminals are located on the bottom right corner (see Fig. 8).



EN

Fig. 8

4. Put the battery packs into the enclosure from left to right and bottom to top and cover each shelf with a fix-plate (see Fig. 9) (please refer to Fig.4 for corresponding battery packs).




Fig. 9

5. Connect the cables to each shelf respectively (see Fig. 10).

REMARK: MAKE SURE TO CONNECT WIRES WITH THE SAME COLOR.





Fig. 10

6. Secure each fix-plate with four screws (see Fig. 11).



EN

7. Tie up the wires properly(see Fig. 12).



8. Reinstall the battery cover and secure it with the eighteen screws.

Label	B1	B2	B3	B4	B5	B6	B7	B8	B9	B10	B11	B12	B13	B14	B15	B16	B17	B18							
Colour	Blk	Red	Brn	Red	Blu	Blu	Blk	Brn	Red	Red	Red	Blk	Blk	Blu	Blu	Blu	Blk	Blu							
Quantity	56	56	8	4	4	4	4	8	1	2	1	1	2	4	1	2	1	1							
Length(mm)	70	70	770	65	65	770	770	65	662	490	152	490	152	262	90	152	90	770	70	462	290	152	290	152	152

5.5 Connecting the external battery

Before connecting the external battery, please read the notice and warning label on the UPS.



Warning!

In the event of malfunction, the battery cabinet chassis or battery cabinet frames may become live!

EN



Warning!

Special care should be taken when working with the battery cabinet associated with the PowerWalker VFI 3/3 Series 30 - 40 kVA. When the battery cabinet is connected the overall voltage exceeds 400V. It is very important to ensure that the batteries are installed separately, in a dedicated battery cabinet.



Notice!

The most common battery type used in UPS installations is the valve regulated battery. Valve regulated cells are not sealed. The amount of gas given off is less than for flooded cells, but when planning the battery installation, allowance must be made for adequate ventilation and heat dissipation. Valve regulated cells are not completely maintenance-free. They must be kept clean and their connections checked periodically to ensure they are tight, and that there is no evidence of corrosion. It is inevitable that the batteries will lose charge during transportation and storage; before attempting to carry out an autonomy test, ensure that the batteries are fully charged as this may take several hours. Cell performance typically improves after a few discharge/recharge cycles.



Notice!

The requirements of the EC directives are satisfied when battery cabinet are used with original accessories. If alternative batteries are used, you must ensure that the applicable EC directives are met and declare conformity.

Connect the battery cabinet as follows:

Turn off the UPS.

Check the internal battery breaker is off and/or any external battery switches open.

Connect PE first.

Connect the battery cabinet(s) with cables sized according to cable cross setion and protective device specification to terminals + (positive pole) ,- (negative pole) and Neutral pole.

Refer to instruction provided with the battery cabinet or by vendor.




Warning!

ENSURE CORRECT POLARITY!

5.6 Connections between battery cabinet and UPS

Make sure the Protective Earthing (PE) connected first.



5.7 Handling the batteries



Warning!

Batteries are a potential source of danger due to their electrical charge and chemical composition. Therefore observe the battery handling instructions of the manufacturer. These usually can be found in the material which accompanies the shipment.

EN

Recharging batteries



Warning!

When recharging, observe the indications on the packaging.

Exchanging batteries



Warning!

Before replacing batteries, make sure that those to be installed are fully charged.

Connecting external battery cabinet




Warning!

If a battery cabinet has been disconnected and is to be reconnected, the battery isolator may only be reconnected after you have made certain that voltage with the correct polarity is present on both sides of isolating device.

6 Software and connectivity

The Series provide Intelligent Slot, Expanded Slot, PARALLEL, AS400, EPO, RS485 and RS232 as well as SERVICE Supervising Communication Interface exclusively available to PowerWalker technical personnel.




1. Intelligent slot: suitable for WebPower card of remote supervising management, enabling you to realize remote supervising management on UPS through Internet.
2. Expanded slot: Reserved for special applications
3. PARALLEL: communication interface for parallel machine mode.
4. Standard AS400 interface: provides AS400 and users can directly use UPS supervising function offered by AS400 system to realize power source management (See Appendix for AS400 port Pin).
5. EPO: Emergency Power Off, providing the possibility of emergency shut down. Normally closed.
6. Standard RS485 Interface: It can be used to monitor parallel units for completely control of UPS (See Appendix for RS485 port Pin).
7. SERVICE Interface: available only to PowerWalker technicians
8. Standard RS232 Interface: applicable to WinPower supervising software of graphic management (See Figure for RS232 port Pin)

RS232 port


Pin #	Description	I/O
2	TXD	Output
3	RXD	Input
5	GND	common

EN




RS485 port

Pin #	Description	I/O
3	RXDA	Input
4	RXDB	Input
5	TXDB	Output
6	TXDA	Output



AS400 port

Pin #	Description	I/O
1	UPS Fail	Output
2	Alarm	Output
3	GND	Common
4	Remote Shutdown	Input
5	Common	Common
6	Bypass	Output
7	Battery Low	Output
8	UPS ON	Output
9	Line Loss	Output



Note!

The UPS have to be manually reset if remote shutdown occurs.

7 User operations



Warning!

High touch current earth connection essential before connecting supply.

The only user operations permitted are:

Start up and shut down the UPS, excluding the commissioning start-up.

Use of the LCD control panel and Emergency Power Off (EPO) switch.

Use of optional connectivity modules and their software.



Warning!

The user must follow the precaution, warnings and only perform the described operation. Any deviations from the user manual could be dangerous to the user or cause accidental load loss.

Should the UPS be intended for application above 1000m, progressive decrease of rated output should be applied as listed in the following chart:

Altitude(M)	1000	1500	2000	2500	3000	3500	4000	4500	5000
Derating coefficient	100%	95%	91%	86%	82%	78%	74%	70%	67%

7.1 Single machine operation

1. Make sure L1, L2 and L3 phase sequences are correctly connected and then supply power to UPS.
2. Close internal battery breaker.
3. Turn on the switch on battery box if the UPS equipped with External battery(make sure that the "+", "N" and "-" of terminal bay are in accordance with those on the battery box).
4. Switch on "Input Switch" (Rectifier Input Switch, Bypass Input Switch) on UPS and fans start to rotate for UPS self-inspection. Main menu can be accessed within about 4sec and then operations should be carried.

Remark: the following drawing takes PowerWalker VFI 30000TP 3/3 BE/BI as an example and statistics are only for reference.


1)Power on




2)Automatic access within about 4s



3)Press ESC to access or automatically within 1min with no button being pressed




4)Press ▼ to obtain the below information



5) Press ▼ again to obtain the below information



6) Press ▼ again to obtain the below information




EN

7) Press ▼ again to obtain the below information




8) Press ▼ again to obtain the below information





Note!


If malfunction occurs, "x" will appear at the lower right corner of the display, while a warning occurs, "△" will appear at the same position (as illustrated in the below picture with battery mode as an example).



4. Start-up action (press ESC to exit the above picture)

1) Switch-on picture


2) Press ENTER



3) Select "Yes, Confirm" to switch on the machine



4) Normal Switch-on



EN

5) Battery power supply (switch off line input switch)




5. Switch-off action (press ESC to exit above picture)


1) Switch-off picture




2) If it is in single machine mode, the following will appear



3) If it is in parallel machine mode, the following will appear



4) Press ENTER



5) Select "Yes, Confirm" to switch off the machine



6) Normal Switch-off



EN

Note!
 If you intend to switch off only one set of UPS among the parallel machine system, select "single machine switch-off"; if switch-off is intended for the entire parallel machine system, select "parallel machine switch-off".

6. Help

1) Help picture



2) Press ENTER on help picture



7. Configuration (press ESC to exit the above picture)

You are able to access Setting picture by using user combination (default: 1234, subject to personal modification) so as to set the following programs.

1) Action display (bypass power supply)



2) Press ▼



3) Enter respective password



4) Select action item



8. The Series is capable of DC start-up without AC input, panel display being similar to switch-on picture with AC supply. DC switch-on and off are available by following instructions appearing in the pictures.

9. Procedures of DC switch-on:

- Activate DC switch-on function set under UPS bypass mode
- Make sure that “+”, “-” and “N” wires of batteries are properly connected to UPS
- Switch on batteries
- Lightly touch ENTER
- Manually conduct switch-on order within about 1min after LCD self-inspection

EN



Note!

UPS will be switched off automatically if there is no operation within 1min after LCD self-inspection is completed!


7.2 Parallel machine operation

Redundancy introduction


N+X is currently the most reliable power supply structure, in which N indicates the minimum UPS number required for the total load and X is the redundant UPS number, namely, the malfunctioning UPS number that the system can simultaneously bear. The larger X is, the higher reliability of system will be. For instance, if the total load of a customer registers 55kVA, we can use 20kVA for N+X design. With N taking up 3, X can be selected in accordance with reliability degree or cost requirement. Supposing customer selects X=2 and equalized UPS power supply is 11kVA for each unit, when one set of UPS breaks down with malfunction, the remaining four sets will provide power with almost 14kVA equalized current; if two sets of UPS fail, the remaining three sets of UPS are supposed to provide power supply with almost 18kVA equalized current. The maximum allowance of this system is for two sets of UPS going down at the same time, the chances of which are much smaller than those of one UPS malfunction. Therefore, the reliability degree can be largely enhanced, making it an optimal mode for application in locations where high degree of reliability is always a focus.

PowerWalker VFI 30000TP, 40000TP 3/3 BE/BI is capable of direct parallel connection, which only requires the parallel connection wires (optional) for 2 to 8 sets of UPS in parallel connection in order to realize power redundancy (N+X).


Parallel machine wire connection drawing(one battery supply)



Parallel machine wire connection drawing(separate battery supply)



Single machine wire connection drawing



EN

8 Maintenance



Warning!

The Maintenance must be performed by a service engineer from the manufacturer or from an agent authorised by the manufacturer.

PowerWalker VFI 30000TP, 40000TP 3/3 BE/BI requires minimum maintenance.

1. If battery is switched off, loaded equipments will not be covered for power-off protection.
2. Make sure UPS vent are properly ventilated and clean side frames and fan vents from dusts every half a year (switch off AC, battery cabinet and internal battery fuse prior to cleaning)

8.1 Battery Maintenance

The battery is key component of the UPS. The battery life depends on the ambient temperature, charge and discharge times. High ambient temperature and deep discharge will shorten the battery life.

1. Sealed maintenance-free lead acid battery be used in the standard. When being connected to the utility power and if the UPS has been turned on, the UPS keeps charging the battery and also offers the protective function of charging and discharging.
2. Keep the ambient temperature between 15°C and 25°C .
3. If the UPS has not been used for a long period, charging is recommended at the interval of 3 months.
4. Normally, the battery should be charged and discharged every 4 to 6 months. Charging should be started after the UPS shut down automatically in the course of discharging. In the regions of hot climates, the battery should be charged and discharged every 2 months. Moreover, the standard charging time should be no less than 10 hours.
5. It's not recommended to replace batteries individually. Complete replacement should follow instructions given by battery suppliers.
6. Under normal conditions, the battery life lasts 3 to 5 years. Should batteries be found in poor performance, replacement should be done as soon as possible only by qualified personnel with proper training. Users are not allowed to replace without authorization.

Remark:

- A. Prior to battery replacement, switch off UPS and remove it from AC and battery, take off internal battery breaker.
- B. Take off metallic articles such as rings and watches.
- C. Use screw drivers equipped with insulated handles and do not place tools or other metallic substances on the batteries.
- D. Short circuit or reverse connection is forbidden for battery polarity connection.

The troubleshooting procedure gives simple remedial if a malfunction occurs in the UPS.

The operator should start the trouble shooting if there is an active alarm indicated on the LCD screen. Service should be contacted if the active alarm is abnormal and displayed as a service code.

Should maintenance prove necessary, the following steps should be followed:

1. Check if UPS input wiring is done properly.
2. Check if all air switches are tripped out.
3. Check if voltage input is within specified range

Please refer to “Light Reference Table” of this User Manual first and then conduct proper treatment. If problems still exist, please record UPS model, serial number as well as purchase date, symptom on fault, light condition, LCD malfunction or warning information.

Table of Malfunctions		
SYMPTOM	LCD DISPLAY OR POSSIBLE CAUSE	SOLUTION
The Fault LED is lit, periodic beeps	Overloaded in bypass or inverter operation mode	Unloaded to the required value
	Mains out of tolerance	Check that the input wiring and input voltage are normal
	Battery disconnected	Check the battery switch and the battery wiring
LCD panel has no display		Switch off and make sure socket is properly connected. Power up again

8.2 Regular service/intervals

The UPS requires very little maintenance if installed in an appropriate environment. In order to ensure maximum availability of the UPS, manufacturer recommends signing a proactive service agreement with a local authorised service provider.

Maintenance	Interval
Batteries change	3-5 years or according to battery suppliers recommendations
Batteries test	18 months
Cooling fan change	5 years

8.3 Cooling fan

The cooling fan lifespan of the UPS unit is about 60 000 operating hours. The actual lifespan depends on the environment and ambient temperature.

Fan failure can be predicted by increasing noise from the fan bearings. The fan replacement is recommended once this symptom starts appearing.

Do not use other than manufacturer's specified spare parts.

9 Parallel systems



Note!

Parallel is only connected to identical ports for the UPS of same models and kVA rating.

EN

- 1) Follow installation instructions for general installation requirements.
- 2) Ventilation spacing between machines should allow for service access.
- 3) Input wiring for each set of UPS should follow the requirements for that of single unit. Each UPS input should be connected to the same input patch board.
- 4) Each UPS output wire should be connected to the output patch board, from which wires are distributed for load as illustrated in following figure.


Remark 1: common battery pack is applicable in parallel machine mode;


Remark 2: each battery pack should be of the same model from the same manufacturer;

Remark 3: requirement of output wiring length:

When the lead from the output terminal of each set of UPS to the output patch board is less than 20m, wire difference should be less than 20%;

When the lead from the output terminal of each set of UPS to the output patch board is longer than 20m, wire difference should be less than 10%.





Note!

Parallel signal cable should be connected as a loop.

11 Display reference Table

EN

Serial No.	working condition	Indicator					BUZZER
		Bypass light	Line light	Inverter light	Battery light	Fault light	
1	Standby Mode						
	Normal					one flashing every 8 sec	one beep every 8 sec
	Warning					one flashing every 4 sec	one beep every 4 sec
	Overload					one flashing every 1 sec	one beep every 1 sec
2	Bypass Mode						
	Normal	●				one flashing every 2 min	one beep every 2 min
	Warning	●				one flashing every 4 sec	one beep every 4 sec
	Bypass phase error or bypass loss	●				one flashing every 2 sec	one beep every 2 sec
	Overload	●				one flashing every 1 sec	one beep every 1 sec
3	Line Mode						
	Normal		●	●			None
	Warning		●	●		one flashing every 4 sec	one beep every 4 sec
	Overload		●	●		one flashing every 1 sec	one beep every 1 sec
4	Battery Mode						
	Normal			●	●	one flashing every 4 sec	one beep every 4 sec
	Warning			●	●	one flashing every 4 sec	one beep every 4 sec
	Low battery voltage			●	★	one flashing every 1 sec	one beep every 1 sec
	Overload			●	●	one flashing every 1 sec	one beep every 1 sec
5	Battery Self Diagnosis Mode						
	Normal	★	★	★	★	None	None
	Warning	★	★	★	★	one flashing every 4 sec	one beep every 4 sec
	Low battery voltage			●	★	one flashing every 1 sec	one beep every 1 sec
	Overload			●	●	one flashing every 1 sec	one beep every 1 sec
6	Fault Mode						
	Normal					Long light	Long beep
7	Converter Mode						
	Normal		●	●		None	None
	Warning		●	●		one flashing every 4 sec	one beep every 4 sec
8	ECO Mode						
	Normal	●		one flashing every 1 min		None	one beep every 1 min
	Warning	●				one flashing every 4 sec	one beep every 4 sec

Should any display or warning message excluded in the above table be found, please contact distributor or call PowerWalker Hot line for advice.

- Indicator light is on
- ★ Indicator light flashes

Warning include one or more than one of these:

- | | |
|-----------------------|--------------------------------|
| 1.EPO active | 11.Charger failure |
| 2.Line loss | 12.Battery over restrict |
| 3.Neutral loss | 13.Battery over temperature |
| 4.Line phase error | 14.Fan over restrict |
| 5.Bypass loss | 15.BUS capacitor over restrict |
| 6.Bypass phase error | 16.Fan failure |
| 7.Battery open | 17.Fan disconnected |
| 8.Low battery voltage | 18.Low temperature Battery |
| 9.Over charger | 19.communication disconnected |
| 10.Battery reverse | 20.Auxiliary charger failure |

